

LAVA/F7000

**NEW CONSTRUCTION
INSTALLATION WATERFREE URINAL**

BEFORE STARTING INSTALLATION

- Check rough-in height to achieve 24" rim height (17" rim height for ADA).
- Check slope. Downhill slope, per code, is essential because waterfree urinals require gravity flow for drainage.
- Check DWV material. Suitable materials include cast iron, PVC, ABS, and galvanized steel.
- **Never install on copper DWV due to copper's susceptibility to corrosion.**

TUBE CUTTING CHART

- Measure drain nipple depth (in inches) to find trim length (in inches)
- 13 7/8" or more **DO NOT CUT TUBE**
- 3 3/4" or less **DO NOT USE TUBE**

OR LESS	TRIM	OR LESS	TRIM	OR LESS	TRIM
13 3/4"	1/4"	10 1/4"	3 3/4"	6 3/4"	7 1/4"
13 1/2"	1/2"	10	4	6 1/2"	7 1/2"
13 1/4"	3/4"	9 3/4"	4 1/4"	6 1/4"	7 3/4"
13	1"	9 1/2"	4 1/2"	6	8
12 3/4"	1 1/4"	9 1/4"	4 3/4"	5 3/4"	8 1/4"
12 1/2"	1 1/2"	9	5	5 1/2"	8 1/2"
12 1/4"	1 3/4"	8 3/4"	5 1/4"	5 1/4"	8 3/4"
12	2"	8 1/2"	5 1/2"	5	9
11 3/4"	2 1/4"	8 1/4"	5 3/4"	4 3/4"	9 1/4"
11 1/2"	2 1/2"	8	6	4 1/2"	9 1/2"
11 1/4"	2 3/4"	7 3/4"	6 1/4"	4 1/4"	9 3/4"
11	3"	7 1/2"	6 1/2"	4	10
10 3/4"	3 1/4"	7 1/4"	6 3/4"		
10 1/2"	3 1/2"	7	7		

CUSTOMER CARE

866-975-0174 or 616-877-4805
service@falconwaterfree.com



CAUTION After removing any urinal from the drain line, it's normal for certain naturally occurring but **potentially hazardous sewer gases** to escape through the opening until the waterless cartridge is installed properly into the waterless urinal. If you need to leave an open drain line unattended after removing the urinal from the wall, temporarily wedge paper towels or a rag into the drain hole to reduce any outflow of sewer gases, and remove the paper towels or rag prior to completing the urinal or cartridge installation. **Never smoke, have an open flame, or place your nose or mouth near open drain lines or waterless urinal housings into which a cartridge is not yet properly installed.** You also can wear a breathing mask when removing or installing any waterless urinal or cartridge to reduce potential exposure to any such gases.

FalconWaterfree.com

The information in this document is subject to change without notice.
©2014 Falcon Waterfree Technologies, LLC. All rights reserved.

1

SET DRAIN LINE HEIGHT 17" from finished floor (standard 24" rim) or 10" for ADA installation. Threaded nipple should extend 1/2 to 3/4" from wall.

2

CARRIER STUD PLACEMENT If using in-wall carrier, set bearing rods as shown above.

3

A. Clean face of existing wall flange.
B. Install the brass flange with the clear inspection disc.
C. Slowly pour water into the drain.
D. Use a flashlight to check the pitch/slope. No water should be present in the inspection disc or nipple.
E. Remove flange after inspection.

4

ADJUST DRAIN TO ACHIEVE PITCH only if standing water is present (code requires 1/4" drop per foot of drain line for proper pitch). Seal wall according to code.

5

MEASURE & MARK THE ROUGH-IN if in-wall carrier is not used. Use a 7/16" masonry bit to drill hole, then install the hanger bracket with one plastic anchor and screw.

6

A. Hang the bowl on the bracket and check tail pipe alignment, then remove the bowl and adjust the bracket as needed. **Re-hang and re-check bowl** alignment with the drain line. Tail pipe should align with center of drain line.
B. Mark anchor holes then remove bowl without moving hanger bracket.

7

DETERMINE THE DRAIN NIPPLE DEPTH by measuring the distance between the back of the sanitary tee (or elbow) to the front edge of the nipple.

8

A. Find the drain nipple depth on the Tube Cutting Chart (left). Measure and mark the specified trim length on the insert tube at the nearest 1/4" groove.

B. Cut the tube at the groove using a sharp utility knife to ensure a square, flat cut.
C. Clean burrs from the cut end by using emery paper.
D. Apply lubricant to the outside of the rubber bushing and ribbed inside area.
E. Insert the tube and bushing with arrow tab at the top. Apply lubricant to tailpipe of housing.

9

PLACE THE GEAR CLAMP and compression nut onto the housing tailpipe.

10

DRILL HOLES with 5/16" masonry bit for the lower anchor screws and insert plastic anchors.

11

HANG THE BOWL, inserting tailpipe into bushing, then install anchor screws with washers. **TIGHTEN FLANGE BOLTS.**

12

TIGHTEN COMPRESSION NUT AND GEAR CLAMP.

13

POUR 5 GALLONS OF WATER as rapidly as possible into housing to ensure good flow and no leaks or standing water.

14

CAULK THE BOWL TO THE WALL if there is good flow and no leaks or standing water.

15

INSTALL CARTRIDGE per the cartridge instruction sheet.